



Zeigerknöpfe (Thermoplast)

Pointer Knobs (Thermoplast) Bouton en plastic avec index



	Farbe	Colour
r	= rot	red
sch	= schwarz	black
ga	= grau	grey
c	= chrom	chromium
b	= blau	blue
ge	= gelb	yellow
gü	= grün	green
br	= braun RAL 8019	brown
be	= beige RAL 1019	beige



Ø d	Knöpfe Knobs	Kappen Caps
4 6	sch sch	r 499.642
		sch 499.643
6	sch	ga 499.644
		c 499.645
		b 499.646
		ge 499.647
		gü 499.648
		be 499.649



Ø d	Knöpfe Knobs	Kappen Caps
6	sch	r 332.662
		sch 332.663
		ga 332.664
		c 332.665
		b 332.666
		ge 332.667
		gü 332.668
be 332.669		




Ø d	Knöpfe Knobs	Kappen Caps
6	sch	r 333.662
		sch 333.663
		ga 333.664
		b 333.666
		ge 333.667
		gü 333.668
		be 333.669

Drehknöpfe (Duroplast)

Knobs (Duroplastic)

mit Zeigerscheibe
with pointer dial



Ø A	B	Ø C	Ø D	E	F	Z	Art.-Nr.
19	16	21	6	5	12	2	320.621
25	22	31,5	6	6	15	1	321.611
31	27	42	6	6,5	19	1	322.611
43	30	58	6	6	21	2	324.621
43	30	58	8	6	21	2	324.821